



UL-PM3052 Fixed Wall Installation

1. Product Features

UL-PM3052 Product weight: 1.9kg; Maximum load: 10kg;
Height Adjustment 250mm-325mm

2. Hardware List

(the below hardware are not included in the product)

I. 6mm spanner II. 10mm spanner III. 8mm star screw driver
IV. 8mm star screw driver V. 8mm spanner
VI. 8mm star screw driver VII. 6mm star screw driver

Important: The Supplier and / or Manufacturer will not be held liable for any personal injury or product damage due to mishandling, incorrect mounting, incorrect assembly or incorrect use of this product.

Note: The supplied wall mounting hardware is not for use on steel stud walls or cold cinder block walls. If you are uncertain what material your wall is constructed of or have any questions regarding the proper installation of this wall mount, contact a qualified contractor. If the hardware required is not included, please contact your local hardware store.

Caution: This wall mount is intended for use on a projector that does not exceed the maximum designated weight capacity. Using this mount with products heavier than the maximum weight indicated may result in instability causing possible injury or damage.

Disclaimer Without Prejudice of Rights

In order to indemnify the Supplier and / or Manufacturer please note that once this product is purchased the Client / Purchaser agrees to the following:

Should the product, in an unlikely event, fail to operate according to its purpose, Interfoto CC hereby declare to repair or replace any part of the mechanism which is found to be defective after full investigation as to the cause. In the case of defects occurring due to an external third party and / or the Client / Purchaser installing it incorrectly, misuse or overloading and / or using it for any other purpose other than that for which it was intended, neglect or damage, external parties repairing or modifying the mechanism in any way and or its spare parts, if the enclosed operating instructions were not followed, the Supplier and / or Manufacturer shall not be held liable for any damage caused to the product placed on the mechanism or wall which the mechanism is attached to or any other property, and personal injury.


















Note: Proof of Purchase to be produced for any claim. This product carries ten years warranty for Manufacture faults / failures.

IMPORTANT SAFETY INSTRUCTIONS









Check your TV user manual instructions to see if there are any special requirements for mounting your TV. If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact:

INTERFOTO CC
Website: www.ultralink.co.za
Email: service@interfoto.co.za
Address: 362 Roan Crescent,
Corporate Park North, Midrand
Tel: +2786 006 1046

Parts list

No.	Description	Specifications Model	Qty
1		Wall plate	x1
2		Join arm-1	x1
3		Join arm-2	x1
4		Square joint	x1
5		U bend joint	x1
6		Panel	x1
7		Projector fittings	x4
8		Plastic cover	x1
A		M5.3x40mm Wallboard screw	x3
B		Φ8 Plastic screw	x3
C		M6x12 Bolt	x2
D		M6x45 Bolt	x3
E		M6x45 Carriage bolt	x2
F		M6 washer	x10
G		M6 Screw nut	x7
H		Plastic lock screw nut	x2
I		M6x16 Carriage bolt	x4

Instructions for installation

J		M6 Screw nut	x1	4	5
K		M5x12 Bolt	x4		
L		M6x12 Bolt	x5		
1			2	 <p>Fix the Join arm-2 to the square joint with the bolt(E and D), washer (F) and screw nut(G and H).</p>	
3	 <p>Fix the square joint to the U bend joint with the bolt(D and E), washer (F) and screw nut(G and H).</p>		6	 <p>Using the bubble level to ensure the wall plate is level, Pre-drill 3 holes with a 8mm bit to 40mm deep. Insert wall anchors into the holes, then use long bolts to mount the wall to studs.</p> <p>Fix the Join arm-2 to the Join arm-1 with the bolt(D) and screw nut(J).</p> <p>Use Long bolt (K or L) to mount projector set to the four projector fittings.</p>	
<p>Fix the U bend joint to the panel with the bolt(L), washer(F) and screw nut(G).</p>		 <p>Fix the projector fittings to the panel with the bolt(I), washer (F) and screw nut(G).</p>			