



UL-PM2533 Fixed Wall Installation

1. Product Features:

UL- PM2533 Product weight: 1.8kg; Maximum load 10kg ; Height adjust 220mm-290mm

2. Hardware List:

(The below hardware is not included with the purchase of this product.)

I. 6mm spanner II. 10mm spanner III. 8mm star screw driver IV. 8mm star screw driver

V. 8mm spanner VI. 8mm star screw driver VII. 6mm star screw driver

Important: The Supplier and /or Manufacturer will not be held liable for any personal injury or product damage due to mishandling, incorrect mounting, incorrect assembly or incorrect use of this product.

Note: The supplied wall mounting hardware is not for use on steel stud walls or cold cinder block walls. If you are uncertain what material your wall is constructed of or have any questions regarding the proper installation of this wall mount, contact a qualified contractor. If the hardware required is not included, please contact your local hardware store.

Caution: This Projector mount is intended for use on a projector that does not exceed the maximum designated weight capacity. Using this mount with products heavier than the maximum weight indicated may result in instability causing possible injury.


















Disclaimer Without Prejudice of Rights

In order to indemnify the Supplier and/ or Manufacturer please note that once this product is purchased the Client/ Purchaser agrees to the following:

Should the product in an unlikely event, fail to operate according to its purpose, Interfoto CC hereby declare to repair or replace any part of the mechanism which is found to be defective after a full investigation as to the cause. In the case of defects occurring due to an external third party and / or the Client / Purchaser installing it incorrectly, misuse or overloading and/ or using it for any other purpose other than that for which it was intended, neglect or damage, external parties repairing or modifying the mechanism in any way and or its spare parts, if the enclosed operating instructions were not followed, the Supplier and /or Manufacturer shall not be held liable for any damage caused to the product placed on the mechanism or wall which the mechanism is attached to or any other property and personal injury.

Note: Proof of purchase to be produced for any claim. This product carries a ten year warranty for manufacture faults/failures.

Parts list

No.	Description	Specifications Model	Qty.
1		Wall plate	x1
2		Join arm-1	x1
3		Join arm-2	x1
4		U bend joint	x1
5		Panel	x1
6		Projector fittings	x4
A		M5.3x40mm Wallboard screw	x4
B		Φ8 Plastic screw	x4
C		M6x16mm Cross round screw	x8
D		M6x30mm Cross round screw	x3
E		M6x16mm flat head screw	x2
F		M6x16 Carriage bolt	x1
G		Butterfly nut	x1
H		M6 Screw nut	x7
I		M6 washer	x9
J		M8 washer	x1
K		Spirit Level	x1

IMPORTANT SAFETY INSTRUCTIONS


Check your projector user manual instructions to see if there are any special requirements for mounting your projector.

If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact:

INTERFOTO CC
Website: www.ultralink.co.za
Email: service@interfoto.co.za
Address: 362 Roan Crescent,
Corporate Park North, Midrand
Tel: +2786 006 1046


Instructions for installation

1




Fix Join Arm-1 to the wall plate with bolt (E).

2




Fix the U bend joint to the panel using bolt (F), Washer (J) and screw nut (H)

3




Fix Join arm- 2 to the square joint with bolt (D), washer (I) and screw nut (G and H).

4



Fix all projector fittings to the Panel using bolt (C), washer (I) and screw nut (H) .


5



Fix Join arm 2 to Join arm-1 using bolt (D) and screw nut (H).

6

Using the spirit level (K) ensure the wall plate is level then Pre-drill 4 holes with a 8mm bit (40mm Deep). Insert Plastic screws (B) into the holes, then use wall board screws (A) to mount to the wall.



Using cross round screw (C), mount the projector into the set four projector fittings.