



ULP-DM1230 Fixed Desk Installation

1. Product Features:

ULP-DM1230 Product weight: 1.6kg ; TV size support: 12"- 30"; Maximum load: 20kg; For Vesa Standard 50 x 50mm, 75 X 75mm , 100 x100mm

2. Hardware List:

(The below hardware is not included with the purchase of this product.)

I. 6mm spanner II. 10mm spanner III. 8mm star screw driver IV. 8mm star screw driver

V. 8mm spanner VI. 8mm star screw driver VII. 6mm star screw driver

Important: The Supplier and /or Manufacturer will not be held liable for any personal injury or product damage due to mishandling, incorrect mounting, incorrect assembly or incorrect use of this product.

Note: The supplied wall mounting hardware is not for use on steel stud walls or cold cinder block walls. If you are uncertain what material your wall is constructed of or have any questions regarding the proper installation of this wall mount, contact a qualified contractor. If the hardware required is not included, please contact your local hardware store.

Caution: This monitor mount is intended for use on a monitor that does not exceed the maximum designated weight capacity. Using this mount with products heavier than the maximum weight indicated may result in instability causing possible injury.



























Disclaimer Without Prejudice of Rights

In order to indemnify the Supplier and/ or Manufacturer please note that once this product is purchased the Client/ Purchaser agrees to the following:

Should the product .in an unlikely event, fail to operate according to its purpose,Interfoto CC hereby declare to repair or replace any part of the mechanism which is found to be defective after a full investigation as to the cause. In the case of defects occurring due to an external third party and / or the Client / Purchaser installing it incorrectly, misuse or overloading and/ or using it for any other purpose other than that for which it was intended, neglect or damage, external parties repairing or modifying the mechanism in any way and or its spare parts, if the enclosed operating instructions were not followed, the Supplier and /or Manufacturer shall not be held liable for any damage caused to the product placed on the mechanism or wall which the mechanism is attached to or any other property and personal injury.

Note: Proof of purchase to be produced for any claim. This product carries a ten year warranty for manufacture faults/failures.

Parts list

No.	Description	Specifications Model	Qty.
1		Wall plate	x1
2		Steel tube	x1
3		Seat post clamp	x1
4		Aluminum joint arm(1)	x1
5		Aluminum joint arm(2)	x1
6		plastic lock screw nut(1)	x1
7		plastic lock screw nut(2)	x1
8		plastic lock part	x1
9		Iron shell	x1
10		Aluminum alloy joint	x1
A		M5x12mm Cross round screw	x4
B		M4x12mm Cross round screw	x4
C		M8x16mm Outer hexagonal screw	x1
D		M8 Iron washer	x1
E		Aluminum alloy insert	x1
F		M8 Screw nut	x1
G		M6X12mm Cross round screw	x2
H		O-ring	x2
I		M10 Copper washer	x2
J		Plastic cover	x1
K		Wrench	x1
L		double side tape	x1
M		M4x4mm Cross round screw	x4
N		Allen wrench	x1
O		M5x12mm flat head screw	x3
P		Spirit Level	x1

IMPORTANT SAFETY INSTRUCTIONS


Check your monitor user manual instructions to see if there are any special requirements for mounting your monitor.

If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact:


INTERFOTO CC
Website: www.ultralink.co.za
Email: service@interfoto.co.za
Address: 362 Roan Crescent,
Corporate Park North, Midrand
Tel: +2786 006 1046

Instructions for installation


1



Fix the panel on the aluminum alloy joint with outer hexagon screw (C), iron washer (D), aluminium alloy insert (E) and screw nut (F).




4



Place the plastic screw through the seat post clamp and steel tube.
Assemble the plastic lock screw, plastic lock park, aluminum assembly and plastic lock screw nut 1.
Hitch the seat post clamp and steel tube, make sure they are connected and then screw down.
Cover the plastic screw.


2



Fix Joint Arm 2 to the wall plate with the cross round screw (G), O- ring (H) and copper washer (I).


Fix the aluminium alloy to Joint Arm 1 with the cross round screw (G), O- ring (H) and copper washer (I).

5



Use Long bolt (A or B) to mount the monitor to the panel.

3



6

