

eSmartCam

USER MANUAL

1 Download App

Download App 'eSmartCam' from 'App Store' or 'Google Play' or scan the QR code as attached (Fig. 1):



Fig. 1

2 Register account and login (Fig. 2 & 3).



Fig. 2



Fig. 3

3 Reset

If the camera is used on other accounts, please reset it. The reset button is at the bottom or rear of the camera. Insert the pin and press it for 3 seconds. After you hear a buzzing sound, it will run automatically and have a 'dong-dong' sound which means it would have reset successfully (Fig.4).




Fig. 4

4 Login and link configuration

When you log in and reset the App for the first time, it will remind you to add the camera function. The camera will have a short buzzing alarm sound which will mean that you can start connection. We have three ways in which we can connect: smart link, QR code configure, LAN configure (Fig. 5 & 6)



Fig. 5

Fig. 6

NOTE: Please make sure use 2.4G Wi-Fi for connection.

4.1 Smart Link

Input Wi-Fi name & password. After 'ding-dong' and continuous buzzing 'be-be', it means successful connection.(Fig. 7 - 12)



Fig. 7

Fig. 8

Fig. 9

Fig. 10

Fig. 11

Fig. 12

4.2 QR code configure

Choose QR code configure and input Wi-Fi name & password. The QR code will be created and shown on screen. Put your smart phone 20-30cm near to camera and scan QR code by lens. After hearing a 'Ding-Dong' and continuous buzzing 'be-be', it means the connection is successful. (Fig.13-20)



Fig. 13

Fig. 14

Fig. 15

Fig. 16

Fig. 17

Fig. 18



Fig. 19

Fig. 20

4.3 LANconfigure(Only supports LAN model with RJ45)

Connect camera with LAN cable under the same network as smart phone. After camera ringing 'Ding-ling', choose it from the list (Fig. 24) and confirm to connect it (Fig. 25).(Fig. 21 - 25)



Fig. 21


Fig. 22

Fig. 23


Fig. 24

Fig. 25

5 The instructions of icons on App




① Multi-picture display ② Adding camera



③ Watch cloud video ④ Sharing camera

⑤ Video playback



⑥ Messages ⑧ Album

⑦ Camera list ⑨ More information

- ① Click it to view multiple cameras (support max 4 cameras in one screen).
- ② Click it to add/connect more camera(s).
- ③ Click to watch cloud video
- ④ Share the camera to other user account(s). If you don't want to share, select the account and slide left to delete it.
- ⑤ Click it to check video playback in TF card.
- ⑥ Pushing pictures from motion/cry detection and sub-account access records is here.
- ⑦ Click it back to camera list.
- ⑧ Snapshot and video clip is here.
- ⑨ Click it for more information such as version number, user video instruction etc.

* The pictures are only for reference. There may be slight differences for different cameras. Please refer to the actual App interface.

Warranty Card

Product Model No.		Purchase Date	
Product Name		Invoice No.	
Factory Serial No.		Customer Name	
Purchase Store		Customer Phone	

Warranty Policy

Thanks for using our product. To obtain better service, please read the following clauses and keep this warranty card properly.

Warranty

1. We provide 12 months limited warranty.
2. We do not replace or refund any sold products except for quality problem.

Disclaimers

This warranty does not cover the following cases:

1. Man-made surface corrosion, break, distortion, or damages due to improper installation, and maintenance.
2. Connecting port is distorted or cracked; PCB is distorted, cracked, damaged or burned; chip is severely burned.
3. The warranty period has expired.
4. Products repaired by unauthorized service provider or personnel, or disassembled by users.

CE FC RoHS
ISO 9001:2008

Made in China

